

Hanging Instructions for Wallpaper
Scrubbable Non-Woven
(untrimmed)

1. Surface Preparation

- Apply a high-quality acrylic primer to the surface before applying adhesive. Allow the primer to dry thoroughly for optimal results.

2. Preparing Wallpaper

- Use the following tools for precise cutting:
 - A large table
 - A long, rigid metal ruler
 - A cutter and fresh cutting blades
- Cut the white margins very straight to ensure perfect, almost invisible joints. Be careful not to scratch the wallpaper surface during manipulation of the large panels.

3. Handling Dark Colors

- For very dark wallpaper, apply a matching dark color along the edges of the paper with a thin brush. This prevents visible white seams after hanging.

4. Hanging Scrubbable Non-Woven Wallpaper

- This wallpaper, noted for its rigidity and pleasant texture, is easy to hang.
- Apply adhesive only to the wall, not to the wallpaper. Select an adhesive specifically designed for non-woven wallpaper.
- Avoid getting adhesive on the printed surface. If adhesive contacts the surface, gently dab it off with a dry cloth and allow it to dry.

5. Smoothing the Wallpaper

- Use a flat brush or a heavy rubber roller to smooth the wallpaper onto the wall. Avoid using plastic scrapers, as they may damage the printed surface.

6. Joining Panels

- While the adhesive is still wet, push the edges of two connecting panels together to eliminate visible seams. Proper hanging should result in completely undetectable seams.